

Ordering the Hose That Fits Your Central Vacuum System



VACUFLO Inlet valves

VACUFLO Inlet Valves

The Vacuflo Inlet Valve's low-voltage contact switches are above the valve opening. The low-voltage connection is made when the low-voltage pins on the hose are inserted into the contact switch.

Vacuflo Inlet Valves DO NOT support electric powerheads or hoses




Universal Inlet valves


Universal Inlet Valves

The Universal Inlet Valve's low-voltage contact switches are inside the valve opening. The low-voltage connection is made when the low-voltage ring on the hose connects with the brass contact switches inside the inlet valve.

Universal Inlet Valves support electric powerheads and hoses only with a pigtail cord.



Universal Inlet valves with pigtail



Direct Connect Electravale

Direct Connect Electravales

The Direct Connect Electravale 110V contact switches are above the valve opening. The electrical connection is made when the pins on the hose are inserted into the contact switch.

Direct Connect Electravales support electric powerheads and hoses.